

TIGER®


MODEL 71-784

game.com™

AC Adapter


Save batteries with this AC Adapter.
Fits all game.com systems.

CAUTION-ELECTRICALLY OPERATED PRODUCT: Not recommended for children under 3 years of age. As with all electric products, precautions should be observed during handling and use to prevent electric shock.




INSTRUCTION:

1. Plug the adapter into the jack on the game.com system.



2. Plug the "brick" into any standard wall or power strip outlet.



- * Unplug the adapter from the electrical outlet when you're finished playing. Clean only with a soft, dry cloth.

MODEL 71-784

game.com™

AC Adapter

Save batteries with this AC Adapter.
Fits all game.com systems.



TIGER®

980 Woodlands Parkway
Vernon Hills, Illinois 60061
1-888-TIGR-SOS
www.game.com

**MADE AND PRINTED
IN CHINA**



Printed on
Recycled Paper

©, TM, & © 1997 Tiger Electronics, Inc.
All rights reserved.



717840001BCTIE-02

SD2358 -7401

TIGER® game.com™

**PLUG IN CLASS 2
TRANSFORMER**



2HB2
LISTED
E144633



LR96264
CERTIFIED

MODEL : DC0900300

INPUT: AC120V 60Hz 10W

OUTPUT : DC9V 300mA

CAUTION-ELECTRICALLY OPERATED

PRODUCT

