

TV-LINK

**CONNECTS YOUR SUPERVISION TO THE TELEVISION
CONECTA TV SUPERVISION A TU TELEVISOR**



TV-LINK



FOR
ONLY
PARA
UNICAMENTE

SUPERVISION

- CARTRIDGE TV GAME SYSTEM
- EXCELLENT SOUND EFFECT
- AUDIO / VIDEO OUTPUTS
- ATTRACTIVE VISION
- DIRECT RF OUTPUT

- CASSETTE PARA EL SISTEMA DE T.V.
- EXCELENTES EFECTOS DE SONIDO.
- CONECCIONES DE ENTRADA DE AUDIO/VIDEO.
- CONECTOR A FRECUENCIA DIRECTA A SU T.V.





FOR
SUPERVISION
ONLY

PARA
SUPERVISION
UNICAMENTE



TV-LINK



SUPERVISION CONNECTION
CARTRIDGE
CASSETTE CONECTOR
SUPERVISION



TV-LINK BASE
BASE TV LINK



AUDIO/VIDEO CABLE
CABLE CONECTOR

INCLUDES:

1. VIDEO SWITCHING BOX
2. SUPERVISION CONNECTION CARTRIDGE
3. AUDIO/VIDEO CABLES
4. TV-LINK BASE SET

USES 4 x 1.5 AA BATTERIES (EXCLUDED)

INCLUYE:

1. CONECTOR DE FRECUENCIA.
2. CASSETTE CONECTOR SUPERVISION.
3. CABLES DE AUDIO/VIDEO.
4. UNIDAD DE TV LINK.

REQUIERE 4 BATERIAS 1.5V AA (NO INCLUIDAS)



MODEL NO. 9307



NTSC



Please keep this package for the information printed on it.
Not suitable for children less than 36 months old.
Some small parts can be removed (batteries and cover)
and might be swallowed accidentally.

Golden Free Trade Ltd.
Tel: (915) 779-2244


SUPERVISION TV-LINK

SECTION 1

SUPERVISION TV-LINK FEATURES


(A) TV-LINK

1. Power Switch (Power)
2. Power-On Indicator
3. Slot for game cartridge insertion
4. Low-Battery Indicator
5. Two-Player Link (comm. port)
6. Socket (connect to SUPERVISION CONNECTION CARTRIDGE)
7. External Power Supply Jack
8. Battery Cover (back)
9. Audio Output
10. Video Output
11. RF Output (connect to television set)



(B) SUPERVISION (Not included in SUPERVISION TV-LINK package)

1. Power Switch (POWER)
2. External Power Supply Jack
3. Contrast Adjustment (CONTRAST)
4. Direction Button
5. Battery Cover (at the back)
6. Headphones Jack (Phones)
7. Speaker
8. "A" & "B" Buttons – Please refer to the game cartridge instruction.
9. Select Button
10. Start Button
11. Volume Dial (VOLUME)
12. Two-Player Link (comm. port)




Machine is bendable

(C) OTHER ACCESSORIES


a. TV CABLE

1. Plug (connect to SUPERVISION TV-LINK / SWITCHING BOX)




b. SUPERVISION CONNECTION CARTRIDGE

1. Plug (connect to SUPERVISION TV-LINK)
2. TV-LINK ADAPTOR cartridge (connect to SUPERVISION)
3. DC Plug (connect to SUPERVISION DC 6V input when using AC-DC Adaptor)




c. VIDEO SWITCHING BOX

1. Connect to TV-LINK
2. Selection Switch (TV-LINK / TV Program)
3. Connect to ANTENNA INPUT of television set
4. Connect to ANTENNA



d. AUDIO/VIDEO CABLE


1. White Plug (connect to TV-LINK Audio Output/Television Set Audio Input)
2. Yellow Plug (connect to TV-LINK Video Output/Television Set Video Input)




SECTION 2

SUPERVISION TV-LINK CONNECTION

(A) USING RF OUTPUT



(B) USING VIDEO/AUDIO OUTPUT



SECTION 3

NOTE FOR BATTERY-USER

- Remove the cover on the back of the SUPERVISION and SUPERVISION TV-LINK and insert four "AA" batteries in each machine.
- Make sure that the batteries, plus (+) and minus (–) ends are facing the right directions.
- Do not use rechargeable batteries.
- Do not use mercury oxide batteries.
- For best results, use alkaline batteries.
- Do not connect the DC plug to SUPERVISION (Section 1, Part C, Point b3).

SECTION 4

HOW TO OPERATE

1. For Battery Users, make sure that BATTERIES have been installed.
2. For AC-DC Adaptor Users, connect DC Plug (from SUPERVISION CONNECTION CARTRIDGE) to the SUPERVISION DC 6V Input. Connect AC-DC Adaptor to the External Power Supply Jack (Section1, Part A, Point 7) of SUPERVISION TV-LINK.
3. Connect SUPERVISION TV-LINK to SUPERVISION by SUPERVISION CONNECTION CARTRIDGE.
4. Connect SUPERVISION TV-LINK to TV-Set with the use of the SWITCHING BOX. Set the switch of the SWITCHING BOX to GAME. (See SECTION 2 for detailed illustration of SUPERVISION TV-LINK connection.) Remarks: Player can watch television without removing the SUPERVISION TV-LINK connection by setting the switch of the SWITCHING BOX to TV.
5. For A/V Output Users, connect the Audio and Video Cable between TV-Set and TV-LINK according to Section 2.
6. Insert a game cartridge into the SUPERVISION TV-LINK slot.
7. Turn on SUPERVISION TV-LINK.
8. Turn on SUPERVISION.
9. Tilt the screen of SUPERVISION and place SUPERVISION on SUPERVISION TV-LINK.

IMPORTANT NOTICE

- When changing a game cartridge, make sure that the power is turned "OFF".
- When inserting a game cartridge into the SUPERVISION TV-LINK slot, please make sure that the side with the LABEL faces down.

SECTION 5

FAULT	SUGGESTED ACTION
The Power-On LED is dark.	<ul style="list-style-type: none">• For battery user: replace batteries.• For AC-DC Adaptor user: check that the DC polarity of the adaptor is correct.
No sound can be heard during the game.	<ul style="list-style-type: none">• Check that the game cartridge is inserted properly.• Adjust TV-Set Volume.
No picture on TV-Set.	<ul style="list-style-type: none">• Select suitable channel on TV-Set, e.g. A/V, Television Channel.
No display on SUPERVISION screen.	<ul style="list-style-type: none">• Check that the SUPERVISION CONNECTION CARTRIDGE is inserted properly.• Check power supply.
The Low-Battery LED is lit.	<ul style="list-style-type: none">• Replace TV-LINK batteries.

SUPERVISION TV-LINK


SPANISH

SECCION 1

CARACTERISTICAS DEL "SUPERVISION TV-LINK"


(A) TV-LINK

1. Interruptor de arranque (Power)
2. Indicador de encendido
3. Ranura para insertar el cartucho
4. Indicador de batería agotada
5. "Two-Player Link" (puerto de comunicación)
6. Enchufe (conecte al cartucho de conexión del SUPERVISION)
7. Conector de Corriente Externa
8. Tapadera de la batería (atras)
9. Salida del sonido
10. Salida del video
11. Salida del RF (conecte a la televisión)



(B) SUPERVISION (no incluido en el paquete de "SUPERVISION TV-LINK")

1. Interruptor de arranque (Power)
2. Conector de Corriente Externa
3. Ajuste del contraste (Contrast)
4. Botón de dirección
5. Tapadera de la batería (atras)
6. Enchufe del audífono (Phones)
7. Bocina
8. Botones "A" y "B" – Por favor refiera a la instrucción del cartucho del juego.
9. Botón para seleccionar
10. Botón para empezar
11. Cuadrante del volumen (Volume)
12. "Two-Player Link" (puerto de comunicación)




La máquina se puede doblar

(C) OTROS ACCESORIOS


a. CABLE DE LA TELEVISION

1. Clavija (conecte al "Supervision TV-Link" / Caja de Distribución)




b. CARTUCHO DE CONEXION DE SUPERVISION

1. Clavija (conecte al "Supervision TV-Link")
2. Cartucho del "TV-Link" adaptador, (conecte al Supervision)
3. Clavija DC (conecte a la entrada del "Supervision DC 6V" cuando use el "AC/DC" adaptador)




c. CAJA DE DISTRIBUCION ENTRE EL VIDEO Y LA TELEVISION

1. Conecte al "TV-LINK"
2. Interruptor de selección (TV-LINK / Programa de televisión)
3. Conecte a la entrada de antena de la televisión
4. Conecte a la antena



d. CABLE DE SONIDO/VIDEO


1. Clavija Blanca (conecte al "TV-LINK" la salida del sonido / entrada del sonido de la televisión)
2. Clavija Amarilla (conecte al "TV-LINK" la salida del video / entrada del video de la televisión)




SECCION 2

CONEXION DEL "SUPERVISION TV-LINK"

(A) USANDO EL LA SALIDA DEL "RF"



(B) USANDO LA SALIDA DEL VIDEO/SONIDO



SECCION 3

NOTA PARA EL USUARIO DE BATERIAS

- Remueva la tapadera detras del SUPERVISION y *SUPERVISION TV-LINK* y inserte cuatro baterias "AA" en cade máquina.
- Asegurese que los terminos positivo(+) y negativo(–) de las baterias apunten a sus derecolones correctamente.
- No use baterias recargables.
- No use baterias de oxido de mercurio.
- Para mejores resultados, use baterias alcalinas.
- No conecte el enchufe "DC" al SUPERVISION (sección 1, parte c, punto b3).

SECCION 4

COMO OPERAR

1. Para el usuario de baterias, asegurese que las baterias hayan sido instaladas.
2. Para el usuario del adaptador "AC/DC", conecte el enchufe "DC" (de la conexión del cartucho de SUPERVISION) a la entrada del "SUPERVISION DC 6V". Conecte el adaptador "AC/DC" al Conector de Corriente Externa. (SECCION 1, Parte A, Punto 7) del "SUPERVISION TV-LINK".
3. Conecte el "SUPERVISION TV-LINK" al SUPERVISION por medio de la conexión del cartucho del SUPERVISION.
4. Conecte el "SUPERVISION TV-LINK" a la televisión con el uso de la caja de distribución. Ponga el botoncillo de la caja de distribución en juego "GAME". (Vea la SECCION 2 para una ilustración detallada de la conexión del "SUPERVISION TV-LINK".
Observaciones: el jugador puede observar la televisión sin quitar la conexión del "TV-LINK" al cambiar el botoncillo de la caja de distribución a television "TV".
5. Para el usuario del "AV Output", conecte el cable del sonido y video entre la televisión y el "TV-LINK" de acuerdo con la SECCION 2.
6. Inserte un cartucho del juego en la ranura del "SUPERVISION TV-LINK".
7. Encienda el "SUPERVISION TV-LINK".
8. Encienda el SUPERVISION.
9. Inclíne la pantalla del SUPERVISION y coloque el SUPERVISION en el "SUPERVISION TV-LINK".

AVISO IMPORTANTE

- Cuando cambie un cartucho del juego, asegurese que la corriente este en "OFF".
- Cuando inserte un cartucho en la ranura del "SUPERVISION TV-LINK", por favor asegurese que el lado con la etiqueta este volteado así abajo.

SECCION 5

DEFECTO	ACCION SUGERIDA
Indicador de Corriente.	<ul style="list-style-type: none">• Para el usuario de baterias: reemplace las baterias.• Para el usuario del adaptador "AC/DC":revise que la polarizadora "DC" del adaptor este correcta.
No se oye el sonido durante el juego.	<ul style="list-style-type: none">• Revise que el cartucho del juego este insertado propiamente.• Ajuste el volumen de la televisión.
No aparece nada en la televisión.	<ul style="list-style-type: none">• Seleccione el canal adecuado en la televisión.
No aparece nada en el SUPERVISION.	<ul style="list-style-type: none">• Revise que le cartucho de la conexión del SUPERVISION este insertado porpiamente.• Revise la corriente.
La luz de "LOW BATTERY LED" esta encendida.	<ul style="list-style-type: none">• Reemplace las baterias del "TV-LINK".

SuperVision

LIMITED WARRANTY

THIS PRODUCT, EXCEPT BATTERY, IS WARRANTED BY **SuperVision** TO THE ORIGINAL PURCHASER TO BE FREE FROM DEFECTS IN MATERIAL AND WORKMANSHIP UNDER NORMAL USE FOR A PERIOD OF ONE YEAR FROM THE DATE OF PURCHASE. DURING THE WARRANTY PERIOD, AND UPON PROOF OF PURCHASE, THE PRODUCT WILL BE REPAIRED OR REPLACED (WITH THE SAME OR SIMILAR MODEL) AT **SuperVision's** OPTION, AT A **SuperVision** AUTHORIZED SERVICE CENTER, WITHOUT ANY CHARGE FOR EITHER PARTS OR LABOR. THIS WARRANTY WILL NOT APPLY IF THE PRODUCT HAS BEEN MISUSED, ABUSED, OR ALTERED.

WITHOUT LIMITING THE FOREGOING, BATTERY LEAKAGE WILL BE PRESUMED TO HAVE RESULTED FROM MISUSE OR ABUSE. IF THE BATTERIES ARE NOT REPLACED BEFORE THEY LEAK WITHIN THE PRODUCT, THE WARRANTY WILL AUTOMATICALLY CANCEL ITSELF.

CAUTION:

As soon as you notice that the screen blurs the game you are playing at that moment, immediately turn off the game and change your batteries. Do not continue to play until you have done the above.

TO OBTAIN WARRANTY SERVICE YOU MUST TAKE OR SEND THE PRODUCT WITH A COPY OF YOUR SALES RECEIPT OR OTHER PROOF OF PURCHASE AND THE DATE OF PURCHASE, TO A **SuperVision** AUTHORIZED SERVICE CENTER. DUE TO THE POSSIBILITY OF DAMAGE OR LOSS, IT IS RECOMMENDED WHEN SENDING THE PRODUCT THAT YOU PACKAGE THE PRODUCT SECURELY AND SEND IT INSURED, RETURN RECEIPT REQUESTED.

Sent to:

**GOLDEN FREE TRADE LTD.
6959 GATEWAY W. STE 303
EL PASO, TX 79925**

SUPERVISION AUTHORIZED SERVICE CENTER

THANK YOU FOR PURCHASING **SuperVision**. THIS PRODUCT HAS BEEN ELECTRONICALLY TESTED. IF YOU HAVE PROBLEMS USING THIS PRODUCT, PLEASE REFER TO THE INSTRUCTION MANUAL. **THANK YOU.**

SuperVision

GRUPO SUPERVISION MEXICO, S.A. de C.V.

GARANTIA LIMITADA

Este producto, excepto las baterías, está garantizado por **GRUPO SUPERVISION MEXICO**. La garantía de este producto es contra defecto directo de fábrica bajo el uso normal de un año iniciado el día de la compra. Dicha garantía será válida únicamente con el recibo de compra original y su caja o empaque original.

El producto será reparado, reemplazado, o cambiado por el mismo modelo o similar a la opción de **SuperVision**. Dicha garantía será sin costo en partes y mano de obra al comprador. La garantía no será aplicada o válida si el producto fue abusado, mal usado, alterado, golpeado, o abierto por una persona ajena a **SuperVision**.

Si sus baterías no son reemplazadas antes de que derramen ácido, el producto quedará automáticamente fuera de garantía.

OJO: En el momento en que usted note que en la pantalla se empieza a distorsionar el juego que tenga en ese momento, inmediatamente apague el aparato y cambie sus baterías sin jugar hasta que haya hecho el debido cambio.

Para obtener el servicio de garantía de **SuperVision**, el solicitante debe dirigirse a la tienda en donde usted compró o adquirió el producto con el original de su nota de compra indicando la fecha de la misma y dentro de su caja original. También podrá dirigirse a:

GRUPO SUPERVISION MEXICO S.A. de C.V.
Blvd. Manuel Avila Camacho #271
Col. Polanco
Mexico, D.F.
C.P. 11510

en las mismas condiciones con su caja original, la nota de compra original, y el número de serie del apartado.

CENTRO DE SERVICIO AUTHORIZADO SUPERVISION

Gracias por la compra de **SuperVision**. Este producto está electrónicamente revisado y comprobado. Si usted tiene algún problema en la información del uso de este producto, por favor recurra al manual de instrucciones. **GRACIAS.**

SuperVision

PLEASE
PLACE
STAMP
HERE

Goldnation (U. S. A.) Inc.
251 E. Redondo Beach Blvd.
Gardena, CA 90248
U. S. A.

NAME			
ADDRESS			
CITY	STATE	ZIP	

Dear Customer:

We at Goldnation (U. S. A.) Inc. would like to thank you for purchasing our product. In order to help us in maintaining our quality line of products and developing new products in the future, we would like to receive your feedback by answering the questions on the warranty information card. Please keep this portion of your warranty after you have mailed your warranty information card to us.

We once again thank for your recent purchase and hope you and your family will satisfy to our product's quality.

Goldnation (U.S.A.) Inc.

Printed in Hong Kong

